




World Travel Adapter With 2USB&3Type-C

PRODUCT OVERVIEW



1. Multi-socket
 - a. LED solid: normal operation
 - b. LED does not light: Possible overload, unplug one device and check status indicator again.
2. US/AU/UK/EU Plugs
3. LED Indicator
4. USB-A1/A2 Ports
5. USB-C1/C2/C3 Ports
6. USB-C4 Ports

PECIFICATIONS


- Model: DV240002
- AC Input: 100V-250V,50/60Hz
- Single port output mode
 - USB-C1/C2/C3:5.0V---3.0A
15.0W,USB-A1:5.0V---2.4A
12.0W
 - USB-C4:5.0V---3.0A
15.0W.9.0V---3.0A

- 27.0W.12.0V---3.0A
- 36.0W,15.0V---3.0A
45.0W,20.0V---3.25A 65.0W
- Combined output mode
 - USB-C1/C2/C3:5.0V---3.0A
15.0W,USB-A1:5.0V---2.4A
12.0W
 - USB-C4:5.0V---3.0A
15.0W,9.0V---3.0A
27.0W.12.0V---3.0A
 - 36.0W,15.0V---3.0A
45.0W,20.0V---2.25A 45.0W


- Total Output: 5.0V 5.6A 28.0W Max
- Operating Temperature: 0°C - 40°C
- Dimensions:
72,5mmx50mmx53.7mm

APPLICABLE OUTLETS


1. Adapter can accept Type A, B, C, E, F, G, I, J, L, N plugs.



Please notice that type D,H,K,M and O plugs are not accepted.



2. Adapter can plug into Type A,B,C,D,E,F,G,H,I,J,K,L,M,N and O outlets.



2-POLE UNEARTHED DEVICES

The product is suitable for use with most electronic devices up to 2500W at

250V and 1000W at 100V. It can be used with a multitude of appliances such as: Laptops, Small travel hair dryers, Travel irons, Electric fan, Table lamp, Electric razors, etc.

Please check the safety data sheet or data plate on the device to find this information before plugging it in.

USB DEVICES

Camera, Smartphone, Tablet, Portable Game Console, Bluetooth speaker, Power bank, etc.


HOW TO USE THE ADAPTER

Features:

Built-in multi-nation plugs can be selected to fit all outlets in different countries. Safety function switch ensure only one plug energized.


Attentions:

1. Please make sure that the button is reset when the button is pushed out and retracted to the bottom, and if the button is not reset, it means that the pug has not been pushed in place and will affect the normal use.
2. Only one plug-type can be used at one time by sliding the knob selection, other plug-pins are locked automatically.




Use AUS Plug

Use USA Plug




Use USA Plug

Use AUS Plug



Use UK Plug

Use UK Plug




Use EU Plug

Use EU Plug

Slightly press the corresponding button and slide to the down for plug completely as shown. Make sure the contact blades are turned to the parallel position.

Recover the plug: press and hold the corresponding button to release and continue to pull up, until the plug completely pulls to the top and then release the button, then the button will reset and lock the plug.

REPLACEMENT OF THE FUSE



1. Take out ❶
2. Take out ❷, and put ❷ into the original position of ❶, the adapter could work again.
3. You also could change new fuse.
standard: 250Vac 10A, 6.3*25.4mm

1. Take out ❶
2. Take out ❷, and put ❷ into the original position of ❶, the adapter could work again.
3. You also could change new fuse.
Standard: 250Vac 10A, 6.3*25.4mm

Notes:

1. You should remove all the device before you change the new fuse.
2. Please confirm whether there is water flowed out from the access equipment in the power rating.
3. Please confirm whether the product is wet and there is water flowed out.

CAUTION

- Always disconnect Adapter from the outlet when not in use.
- Before use, please read this instruction carefully! This product does not convert voltage(AC-AC), in order to avoid possible damage to your device or other safety hazards, please make sure the power outlet you intend to use has the proper voltage to run your device before using this adapter.
- Indoor use only.
- Misuse can lead to electrical shock.
- The length of the USB cable should be less than 3M.
- The travel adaptor is for temporary use only and it shall not be used permanently.

- Do not insert an adaptor into another adaptor.
- No grounding. This product is for use with unearthed or double insulated appliances only.

COMPATIBLE COUNTRIES

EU PLUG:

Albania, Algeria, Angola, Argentina, Austria, Azores, Balearic Islands, Bangladesh, Belgium, Bolivia, Bosnia, Brazil, Bulgaria, Burkina Faso, Burundi, Cameroon, Canary Island, Cape Verde, Central African Republic, Channel Islands, Chile, Comoros, Congo, Croatia, Cote d' Ivoire, Cyprus, Denmark, Djibouti, Egypt, El Salvador, Equatorial Guinea, Eritrea, Faeroe Islands, Finland, France, Gabon, Germany, Gibraltar, Greece, Greenland, Guadeloupe, Guinea, Guinea-Bissau, Hungary, Iceland, India, Indonesia, Iran, Iraq, Israel, Italy, Kazakhstan, Korea, Kuwait, Laos, Lebanon, Lithuania, Luxembourg, Macedonia, Madagascar, Madeira, Mali, Martinique, Mauritania, Mauritius, Monaco, Morocco, Mozambique, Myanmar, Nepal, Netherlands, Niger, Norway, Oman, Pakistan, Paraguay, Peru, Philippines, Poland, Portugal, Romania, Russia, Rwanda, Senegal, Somalia, Spain, Sudan, Suriname, Sweden, Switzerland, Syria, Thailand, Togo, Tunisia, Turkey, Uruguay, Vietnam, Zambia.

AUS PLUG:

American Samoa, Argentina, Australia, China, El Salvador, Fiji, Guatemala, Kiribati, Nauru, New Zealand, Panama, Papua New Guinea, St. Vincent, Tajikistan, Tonga, Uruguay.

USA PLUG:

American Samoa, Anguilla, Antilles, Aruba, Bahamas, Bangladesh, Barbados, Bermuda, Bolivia, Brazil, Cambodia, Canada, Cayman Islands, China, Colombia, Costa Rica, Cuba, Ecuador, El Salvador, Guam, Guatemala,

Guyana, Haiti, Honduras, Japan, Jamaica, Laos, Lebanon, Liberia, Maldives, Mexico, Micronesia, Montserrat, Netherlands, Nicaragua, Niger, Okinawa, Panama, Peru, Philippines, Puerto Rico, St. Vincent, Saudi Arabia, Tahiti, Taiwan, Yemen

UK PLUG:

Bahrain, Bangladesh, Belize, Botswana, Brunei, Cameroon, Channel Islands, Cyprus, Dominica, El Salvador, Gambia, Ghana, Gibraltar, Grenada, Guatemala, Guyana, Hong Kong, Iraq, Ireland, Isle of Man, Jordan, Kuwait, Lebanon, Macau, Malawi, Malaysia, Maldives, Malta, Mauritius, Myanmar, Nigeria, Oman, Qatar, St. Lucia, St. Vincent, Saudi Arabia, Seychelles, Sierra Leone, Singapore, Tanzania, Uganda, United Arab Emirates, United Kingdom, Vietnam, Yemen, Zambia, Zimbabwe



Waste Electrical Products Disposal

- Do not dispose of with household waste
- Please recycle where facilities exist
- Check with your Local Authority for recycling advice



RoHS