

Type-C 9-in-1 USB Hub User Manual



1. Introduction

Thank you for purchasing our USB Hub. This manual will guide you through the installation, usage, and troubleshooting of your new USB Hub. Please read this manual carefully before using the device.

2. Package Contents

- 9-in-1 USB Hub

3. Features

- **9-in-1 USB Hub:** Provides multiple ports for various devices.
- **Type C Hub:** Includes 2 USB 3.0 (A), 3 USB C, HDMI, SD Card slot, Micro SD card slot, RJ45 Ethernet port.
- **Aluminum Housing:** Durable and stylish design.
- **Plug and play:** No driver required.
- **Compatible:** Works with USB 2.0/3.0/3.1 devices.
- **High-speed data transfer:** Supports data transfer rates up to 5 Gbps (for USB 3.0).
- **Overcurrent protection:** Ensures safe operation.

4. Specifications

Port	Q'TY	Spec.
USB3.0 A/F	2	5 Gbps
USBC/F	2	5 Gbps
USBC/F	1	PD/100W
HDMI/F	1	4K 60Hz
SD	1	3.0
Micro SD	1	3.0
RJ45	1	10/100/1000

5. Installation and Setup

Step 1: Unpack the USB Hub

Carefully remove the USB Hub from the packaging.

Step 2: Connect to Computer

1. Connect the USB Hub to an available USB port on your computer using the provided USB cable.
2. If your model requires an external power adapter, connect it to the USB Hub and plug it into a power outlet.

Step 3: Connect Devices

Plug your USB devices (e.g., mouse, keyboard, flash drive) into the available USB ports on the hub.

Step 4: Verify Installation

Your computer should automatically recognize the USB Hub and install any necessary drivers.

6. Usage Instructions

- **Data Transfer:** Connect storage devices to transfer files. Ensure you safely eject devices before unplugging them to avoid data loss.
- **Charging:** If the hub supports charging, connect your device to the appropriate port for charging. Note that charging speed may vary based on the power source and device.
- **Video Output:** Use the HDMI port to connect to a display that supports 4K 60Hz output.
- **SD Card Access:** Insert your SD card into the SD slot for data transfer.
- **Micro SD Card Access:** Insert your Micro SD card into the Micro SD slot for data transfer.
- **Network Connection:** Use the RJ45 port to connect to a wired network for stable internet access.

7. Troubleshooting

Problem: USB Hub not recognized by computer

- Ensure the USB Hub is properly connected to the computer.
- Try connecting the USB Hub to a different USB port on the computer.
- Restart your computer.

Problem: Connected devices not working

- Check if the devices are properly plugged into the USB Hub.
- Try connecting the devices directly to the computer to ensure they are working properly.

Problem: Slow data transfer rates

- Ensure you are using USB 3.0 ports and cables for high-speed transfers.
- Check for other devices that may be using the same bandwidth.

Problem: No network connection through RJ45 port

- Ensure the Ethernet cable is properly connected to the RJ45 port.
- Check the network settings on your computer to ensure it recognizes the wired connection.
- Restart your computer and the router.

8. Safety Information

- Do not expose the USB Hub to moisture or extreme temperatures.
- Avoid dropping or subjecting the USB Hub to strong impacts.
- Keep the USB Hub away from flammable materials.
- Disconnect the USB Hub from power before cleaning. Use a dry cloth for cleaning.