DVICED

Type C to USB A 3.0 Adapter
User Manual

1. Introduction

Thank you for purchasing our Type C to USB A 3.0 Adapter. This manual will guide you through the installation, usage, and troubleshooting of your new adapter. Please read this manual carefully before using the device.

2. Package Contents

- Type C to USB A 3.0 Adapter

3. Features

- **High-Speed Data Transfer**: Supports USB 3.0 with data transfer rates up to 5 Gbps.
- **Compact and Portable**: Small size for easy carrying.
- **Durable Design**: Made with high-quality materials for long-lasting use.
- **Plug and Play**: No drivers required.
- **Backward Compatible**: Works with USB 2.0 and 1.1 devices.
- **Versatile Use**: Compatible with various devices including laptops, tablets, and smartphones with a Type C port.

4. Specifications

- **Connector 1**: Type C Male
- **Connector 2**: USB A 3.0 Female
- **Data Transfer Rate**: Up to 5 Gbps
- **Compatibility**: USB 1.1, 2.0, and 3.0
- **Material**: Aluminum alloy housing

5. Installation and Setup

Step 1: Unpack the Adapter

Carefully remove the adapter from the packaging.

Step 2: Connect to Device

1. Insert the Type C connector into the Type C port of your device (e.g., laptop, tablet, smartphone).
2. Connect your USB A device (e.g., flash drive, keyboard, mouse) to the USB A port on the adapter.

Step 3: Verify Connection

Your device should automatically recognize the adapter and any connected devices.

6. Usage Instructions

- **Data Transfer**: Use the adapter to connect USB A devices for data transfer. Ensure you safely eject devices before unplugging them to avoid data loss.
- **Charging**: Use the adapter to connect USB A charging cables to charge compatible devices. Note that charging speed may vary based on the power source and device.

7. Troubleshooting

Problem: Adapter not recognized by device

- Ensure the adapter is properly connected to the Type C port.
- Try connecting the adapter to a different Type C port on your device.
- Restart your device.

DVICED

Problem: Connected devices not working

- Check if the devices are properly plugged into the adapter.
- Ensure the adapter is receiving power.
- Try connecting the devices directly to your device to ensure they are working properly.

Problem: Slow data transfer rates

- Ensure you are using USB 3.0 ports and cables for high-speed transfers.
- Check for other devices that may be using the same bandwidth.

8. Safety Information

- Do not expose the adapter to moisture or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Keep the adapter away from flammable materials.
- Disconnect the adapter from your device before cleaning. Use a dry cloth for cleaning.